## ASSIGNMENT 12

Textbook Assignment: "Direct Leveling and Basic Engineering Surveys." Pages 14-25 through

- Fieldwork on the construction of a 12-6. Your survey party is assigned the 12-1. road being built on a 5-year-old naval air station would very likely begin with what type of survey?
  - Final location Topographic 1.

  - 3. Reconnaissance
  - 4. As-built
- What is the first step in a 12-2. reconnaissance survey?
  - A field trip to the desired location
  - A study of existing maps and aerial photographs
  - 3. An instrument survey of the desired location
  - 4. An inventory of available construction equipment
- 12-3. Direct air observation of an area to be reconnoitered offers what main advantage?
  - Acquiring information about the relief of the area
  - Providing a quick means of preparing sketches of the area
  - 3. Speeding subsequent ground reconnaissance of the area
  - 4. Providing a quick means of preparing maps of the area
- A field reconnaissance party follows the route previously marked on a map to verify actual conditions on the ground. Which of the following conditions, relative to an engineering study, should be noted?
  - 1. Soil conditions and washout

  - Vegetation and obstacles
     Quarry sites and sand or gravel deposits
  - 4. All of the above
- Which of the following tasks in 12-5. constructing a highway is part of the preliminary survey?
  - Establishing final grades and alignments
  - 2. Computing the highway right-of-way
  - 3. Running the traverse
  - 4. Setting grade stakes

- task of completing a reconnaissance survey of a 3-mile road in hilly, wooded terrain. For this survey, your party should carry which of the following equipment?
  - Lensatic compass
  - 2. Brush hook
  - 3. Hand level
  - 4. All of the above
- 12-7. As the lead surveyor laying out the final location of a roadway center line, you suspect that the preliminary survey was in error regarding the exact location of the center line. Which of the following actions should you take?
  - 1. Lay out the center line according to the preliminary data
  - 2. Lay out the center line the way you know it should be
  - 3. Lay out the center line and then report the reason for making the necessary change
  - 4. Report the problem and receive authorization before making the location change
- 12-8. Which of the following details must be shown on a plan view of a proposed highway?
  - Curve design data
     Gradient

  - 3. Spot elevations
  - 4. Typical cross section of the highway
  - 12-9. When plotting a profile, you should use which of the following (a) horizontal and (b) vertical scales?
    - (a) 1" = 200' (b) 1" = 20'
    - 2. (a) 1" = 20' (b) 1" = 200'
    - 3. (a) 1" = 135' (b) 1" = 15'
    - 4. (a) 1" = 205' (b) 1" = 20'

- 12-10. You have just plotted the profile of a road section from station 6 + 00 to station 9 + 81. The elevation of station 6 + 00 is 100.00 feet and that of station 9 + 81 is 93.30 feet. What is the gradient between these stations?
  - +1.76%
  - 2. -1.76%
  - 3. +17.60%
  - -17.60%

- 12-11. What kind of information is presented in the typical cross section of a proposed highway?
  - Design data for the highway
  - Details of the representative terrain over which the highway will be built
  - 3. Factors establishing a need for the highway
  - Schedule of the office tasks to be performed before the construction of the highway




Figure 12A

IN ANSWERING QUESTIONS 12-12 THROUGH 12-15, REFER TO THE CROSS SECTION OF THE PROPOSED HIGHWAY SHOWN IN FIGURE 12A.

- 12-12. What is the finished grade elevation?
  - 260.4 ft
  - 2. 248.7 ft
  - 244.6 ft 3.
  - 4. 220.0 ft
- How should you write the side slope 12-13. ratio?
  - 1. 1:2
  - 2. 2:1
  - 1/2 3.
  - 2/1
- 12-14. What type of cross section is shown?
  - Level 1
  - 2. Five-level
  - Three-level 3.
  - Four-level

- 12-15. This cross section may also be called what type of section?
  - 1. Regular
  - Irregular 2.
  - 3. Standard
  - Sidehill 4.
- 12-16. On the cross-section paper most widely used in surveying offices, the horizontal lines are spaced how far apart?
  - 1/20 in 1.
  - 1/10 in 2.
  - 3.
  - 1/5 in 1/4 in 4.
- 12-17. After the surface elevations have been plotted on the cross-section paper, the points should be connected in which of the following ways?
  - By freehand curves
  - By freehand straight lines
  - By lines drawn with a straightedge
  - Either 2 or 3 above

- 12-18. In the plotting of cross sections, the vertical scale relates to the horizontal scale in which of the following manner?
  - The vertical scale must be equal to the horizontal scale
  - The vertical scale must be exaggerated from the horizontal scale
  - 3. The vertical scale may be equal to the horizontal scale, or it may be exaggerated for clarity
  - 4. The vertical scale is usually less than the horizontal scale, but it may be equal or exaggerated for clarity

IN ANSWERING QUESTIONS 12-19 THROUGH 12-21, REFER TO FIGURE 14-29 IN YOUR TEXTBOOK.

- The plotted cross sections are 12-19. called irregular for what reason?
  - Sections are plotted at a full station and at a section between two full stations
    The vertical and horizontal
  - scales are different
  - 3. Intermediate elevations are plotted at varying distances from the center line
  - 4. More elevations were plotted for the section at station 11 + 00 than for the section at station 11 + 43
- 12-20. Notice that the cross-section notes show only two ground elevations to the right of the center line at station 11 + 43. Assume that an additional reading could have been obtained at a point 10 feet to the right of the center line but was not. Refer to the plotted cross section of the station and furnish the entry for this point.
  - 5.1 (80.1)
  - 10\_\_\_ 2. 8.6 (67.0)
  - 10 3. 2.4 (74.3)
  - 4. (67.0)

- 12-21. The HI for station 14 + 00 is
  - 76.70
  - 2. 78.90
  - 3. 81.60
  - 85.22
- 12-22. What points are plotted in a three-level section?
  - The roadway edges, slope stakes, and center line
  - The depth of cut or fill and the amount of earth to be moved
  - 3. The left-hand slope stake, right-hand slope stake, and center line
  - The left-hand roadway edge, right-hand roadway edge, and center line
- 12-23. During what stage of a road construction project are "blue tops" used?
  - 1. Rough grading
  - 2. Clearing and grubbing
  - 3. Final grading
  - 4. Paving
- 12-24. The natural earth surface below the pavement of a highway is called the

  - 1. final grade 2. finish grade 3. rough
  - 3. rough grade4. subgrade

  - Which of the following markings on 12-25. a grade stake indicates a cut of 2.6 feet?
    - 1. c 2<sup>6</sup>
    - $2. 2^{\frac{6}{}}$
    - v 2<sup>6</sup>
    - 4. Each of the above
  - 12-26. You wish to indicate a cut of 2.6 feet on a stake that is not a centerline stake. You should write the cut information on what part of the stake?
    - 1. Front
    - 2. Back
    - 3. Right side
    - 4. Left side

IN ANSWERING QUESTIONS 12-27 AND 12-28, YOU ARE SETTING GRADE STAKES BY THE PROCEDURE THAT INVOLVES COMPLETING THE NECESSARY COMPUTATIONS WHILE AT EACH STATION.

- 12 27You can obtain the grade rod by taking the difference between what two measurements?
  - The HI and the ground elevation
  - The HI and the finished grade 2.
  - The finished grade and the ground elevation
  - The width of the highway and the width of the fill or cut
- 12-28. You can obtain the amount of cut or fill for a given station by computing the sum of or difference between what two measurements?
  - The HI and the finished grade
  - 2. The ground elevation and the ground rod
  - The ground rod and the grade
  - The HI and the ground rod

IN ANSWERING QUESTIONS 12-29 AND 12-30, YOU ARE SETTING A CENTERLINE GRADE STAKE AT A STATION WHERE THE EXISTING GROUND ELEVATION IS 98.6 FEET AND THE REQUIRED ELEVATION IS 110.3 FEET.

- At this station, you obtain a reading of 6.3 feet. What is the (a) grade rod and (b) ground rod?
  - 6.3 (b) 104.9 (a)
  - 2. (a) 5.4 (b) 6.3
  - 3. (a) 6.3 (b) 5.4
  - (a) 104.9 (b) 5.4
- 12-30. What information should you mark on the front of the grade stake?
  - $C 5^{\frac{4}{}}$  and the station number
  - 2. F  $6^{\frac{3}{2}}$  and the station number
  - 3.  $\mathbf{G}$  and the station number
  - 4. F  $11^{\frac{7}{2}}$  and the station number
- 12-31. What is the slope stake distance from the center line if W/2 . 18 feet, h = 6 feet, and the slope ratio is 2:1?
  - 1. 21 ft
  - 2. 24 ft 30 ft
  - 3.
  - 4. 42 ft

OUESTIONS 12-32 AND 12-33 PERTAIN TO THE SETTING OF SLOPE STAKES FOR A CUT SECTION. THE DISTANCE FROM THE CENTER LINE TO THE BEGINNING OF THE SIDE SLOPE IS 22 FEET. THERE IS A CROSSFALL OF 0.5 FEET AND A DITCH 2 1/2 FEET IN DEPTH. THE SIDE SLOPE AND BACK SLOPE RATIO IS 3:1, AND h IS 8FEET.

- What is the value of W/2? 12-32.
  - 7.5 ft 1.
  - 22.0 ft 2.
  - 3. 29.5 ft
  - 38.5 ft
- 12-33. What is the slope stake distance from the center line?
  - 24.0 ft
  - 29.0 ft 2.
  - 44.0 ft 3.
  - 4. 62.5 ft

As rodman, you are setting slope stakes at station 7 + 00, and the instrumentman is 100 yards away. You have obtained the following information from notes and plans:

W/2 = 20 FEET SLOPE RATIO = 2:1 FINISHED GRADE ELEVATION AT CENTER LINE = 156.3 FEET GROUND ELEVATION AT CENTER LINE = 160.8 feet HI = 165.0 FEET

## Figure 12B

IN ANSWERING QUESTIONS 12-34 THROUGH 12-38, REFER TO FIGURE 12B.

- 12-34. What is the cut at center line?
  - 1. 4.2 ft
  - 2. 4.5 ft
  - 3. 4.8 ft
  - 4. 8.7 ft
- 12-35. What should the rod reading be at the center line?
  - 1. 4.2 ft
  - 2. 4.5 ft
  - 3. 4.8 ft
  - 4. 8.7 ft

- 12-36. What should your initial estimate of d be?
  - 1. 20.0 ft
  - 2. 28.4 ft
  - 3. 29.0 ft
  - 4. 40.0 ft
- 12-37. As you walk to the initial estimate of d, you observe a drop of approximately 3 feet in the ground elevation. Your second estimate of d is
  - 1. 23.0 ft
  - 2. 25.4 ft
  - 3. 32.0 ft
  - 4. 47.0 ft
- 12-38. At the second estimate of d, the rod reading is 7.2 feet. You know your second estimate of d is
  - 1. correct
  - 2. 0.5 ft short
  - 3. 0.5 ft long
  - 4. 1.0 ft long




Figure 12C

REFER TO FIGURE 12C.

- What type of cross section is 12-39. shown?
  - Level 1
  - 2. Three-level
  - 3. Five-level
  - Sidehill
- 12-40. What is the distance from the center line to the slope stake?
  - 1. 25.4 ft
  - 2. 27.4 ft
  - 3. 27.6 ft
  - 32.4 ft 4.
- 12-41. In curb construction, construction crews should obtain line and grade from which of the following sources?
  - Center-line stakes 1.
  - 2. Blue tops
  - 3. Shoulder stakes
  - 4 Offset hubs
- Pavement stakeout is primarily dependent upon which of the 12-42. following factors?
  - The type of instruments used to perform the stakeout
  - The type of equipment used for paving
  - 3. The finish grade elevations
  - 4. The directions from the construction crew leader
- 12-43. In checking the accuracy of a 9- by 12-foot rectangular layout by means of the Pythagorean theorem,
  you should find the diagonal to

  12-49. Which of the following actions
  should you take when you are measure what distance?
  - 1. 15 ft
  - 2. 18 ft
  - 3. 20 ft
  - 4. 25 ft
- The batter boards should be placed 12-44. how far from the building lines so as not to interfere with construction?
  - 1 to 2 ft 1.
  - 2. 2 to 3 ft
  - 3. 3 to 4 ft
  - 4. 4 to 5 ft

- IN ANSWERING QUESTIONS 12-39 AND 12-40, 12-45. When batter boards are used to preserve building lines, horizontal and vertical controls are provided
  - cords stretched between the top edges of the batter boards
  - 2. the side edges of the batter boards
  - the vertical edges of the batter boards
  - 4. the top edges of the stakes that hold the batter boards
  - 12-46. The invert elevation of an underground sewer pipe is taken at what point on the pipe?
    - Lowest outside surface
    - 2. Highest inside surface
    - 3. Lowest inside surface
    - 4. Highest outside surface
  - 12-47. For any construction project, what is the optimum time for the as-built survey to begin?
    - During the layout survey
    - 2. As soon as stakeout is completed
    - 3. Upon final project completion
    - 4. During construction as the individual features are completed
  - Red flagging should be used on the 12-48. legs of your instrument when you are surveying in the vicinity of which of the following areas?
    - 1. Airstrips
    - 2. Excavations
    - 3. Logging operations
    - 4. Blasting operations
    - should you take when you are running a tape-transit traverse that crosses electric wires?
      - 1. Stretch the tape above the wires
      - 2. Ground one end of the tape
      - Break chain at the wires
         Wear rubber gloves
  - 12-50. Excavations that are what minimum depth, in feet, must be suitably braced and shored to prevent cave-ins?
    - 1. 5 2. 2

    - 3. 3
    - 4. 4